


Getting Started

Thank you for choosing our signal jammer. Allow us to provide you with an introduction and a clear understanding of the button placements, accessory functions, and other hardware features.



Left-side View



Power Pilot Lamp

Power Switch

DC 12V IN Power Jack

Right-side View



Cooling fans insided



JAMMER MASTER

Top-side View

Channel Number



SMA Female Connector

Power Adjust Switch



Cooling Fans

OMINI Antennas

Unboxing and Initial Setup

Carefully open the packaging and retain it for potential future use, such as storage or shipping purposes. Ensure that all components are in good condition. If you encounter any damaged or defective items, please [contact us](#) immediately.

Connecting the System

Connect the antenna one by one based on the specified channel number. Once all antennas are connected, plug one end of the power supply cable into the device's power port and the other end into the power supply jack.

Powering On Your Jammer

Press the switch of the left side to ON then the jammer will be working normally. The power pilot lamp will be green

Adjustable Settings



Locate the adjustable switch on the system to fine-tune the RF power output level for each band or to turn off specific bands without affecting the operation of others.

Powering Off Your Jammer

To power off the jammer, simply toggle the switch on the left side to the "OFF" position.

Important Notices

- ⦿ Do not switch on the power supply before connecting all antennas.
- ⦿ Do not remove antennas while the mainframe is in operation.
- ⦿ Ensure proper ventilation when installing the jammer.
- ⦿ Position the antennas vertically to the ground for optimal performance.
- ⦿ If using the jammer in a vehicle, make sure to connect it to the correct DC12V battery terminals. The minimum output power of the storage battery should be at least 250Watts.



JAMMER MASTER